

Alpha Pipe Liner

1, 26/03/2007

Pipe Lining Slurry

Product description

Alpha Pipe Liner is used to line the screed pipes before pumping either Floor 4480 Alpha+ or 4490 Alpha screeds. It is necessary in order to provide lubrication so that the Alpha product flows smoothly through the screed pipes. Without the lubrication the heavy aggregates segregate and become lodged in the pipes and the whole system will become blocked up.

Mixing

Add the Alpha pipe liner powder to approx 10 litres of water and mix with a paddle mixer until it makes a creamy liquid.

Hand held paddle mixer

Application

- Mix approx. 10 litres of Alpha Pipe Liner in a bucket to a creamy consistency.
- Pour the Alpha Pipe liner into the second mixing chamber.
- Start the pump until the chamber is empty.
- Mix the Alpha product and pump this through behind the Alpha Pipe liner.
- Leave the pump to run until all the slurry is pumped through the screed hoses.
- Pump the slurry into a bucket which can be removed before the Alpha product arrives.

Practical advice

Always pour slurry into SECOND mixing chamber. Never pour slurry into the dry mixing chamber or material trough.

Cleaning and Cares

Wash tools with water.

Storage

12 months under dry conditions.



Saint-Gobain Weber Ltd

Dickens House
Enterprise Way
Maulden Road, Flitwick
Bedford MK45 5BY, UK
Tel: 08703 330070
Fax: (01525) 718988
e-mail: mail@netweber.co.uk